



Key no.	Part no.	Description	q'ty	Key no.	Part no.	Description	q'ty
1	S/R	Air Outlet Barrier	1	34	S/R	Low Voltage Tube	1
2	4512.550	Air Filter	1	35	S/R	Trine Connection Tubei	1
3	4512.551	Humidity Sensor	1	36	S/R	High Volatge Tube	1
4	S/R	Heat Exchanger	1	37	S/R	Hot Gas	3
5	S/R	Electrical Appliance Panel Subassembly	1	38	S/R	Defrost Capillary Tube	1
6	S/R	Bolt	6	39	S/R	High Voltage Tube li	1
7	4512.562	Air Outlet Protection Net	1	40	S/R	Bottom Plate Subassembly	1
8	S/R	Bolt	1	41	4512.565	Water Outlet	1
9	4512.552	Display Panel	1	42	4512.571	Corner Shelf	1
10	S/R	Top Cover Subassembly	1	43	S/R	Bolt	4
11	4512.567	Handle	2	44	S/R	Nut	4
12	4512.553	Film Switch	1	45	S/R	Spring Mat	4
13	S/R	Bolt	4	46	S/R	Flat Mat	4
14	4512.568	Hand Handle	1	47	4512.572	Bottom Feet Sheath	2
15	4512.554	Pcb Panel	1	48	4512.560	Wheels	2
16	S/R	Controller Bracket	1	49	S/R	Hatch Bolt	4
17	S/R	Capacitor Hoop	1	50	S/R	Bolt	6
18	4512.569	Capacitor(Motor)	1	51	4512.561	Axle Hoop	1
19	4512.570	Capacitor(Compressor)	1	52	4512.559	Water Tube	1
20	S/R	Air Path Ply	1	53	S/R	Compressor Mat	3
21	4512.555	Motor Fixation Nut	1	54	S/R	Compressor Nut	3
22	4512.556	Spring Mat	1	55	4512.573	Compressor	1
23	4512.557	Flat Mat	1	56	S/R	Air Outlet Tube I	1
24	4512.563	Fan Blade	1	57	S/R	Air Inlet Tube I	1
25	S/R	Helicoid Cover	1	58	S/R	Fourfold Connection Filter	1
26	4512.564	Motor	1	59	S/R	Trine Connection Tubei	1
27	S/R	Power Wire	1	60	S/R	Air Outlet Tube li	1
28	S/R	Wire Protection Round	1	61	S/R	Trine Connection Tube li	2
29	S/R	Back Side	1	62	S/R	Air Outlet Tube li	1
30	S/R	Wire Connection Seat	1	62	S/R	Fixation Piece	1
31	4512.558	Temperture Sensor	1	63	S/R	Front Bar	1
32	S/R	Temperture Sense Head Receptacle Tube	1	not shown	4512.566	Axle	1
33	S/R	Water Collection Plate	1				

S/R = Parts available on special request only